

Walkaround

Chocks/Tiedowns Removed
Pitot/Static/Vent Covers Removed
Oil Level, Fuel Level Checked
Control Locks Removed
Passenger Briefing Complete

Before Start

Flight Controls Free and Correct
EFIS Bus, CO Detector On
Master/Alternator On
Flaps Up
Strobes On
Tank Selector Fullest
Mixture Rich
Purge Valve Open
Fuel Pump On 3 seconds
Purge Valve Closed
Throttle Closed/Idle
Prop Forward
Mixture Cold-Rich, Hot-ICO
Seatbelts Secure

Engine Start

Brakes On
Mags On
Prop Clear Confirm, announce, confirm
Engine Start
Oil pressure Confirm green
All switches, radio, transponder On
Mixture Lean aggressively
Altimeter/QNH Field Elevation

Taxi

Brakes Check

Run-up

Oil Temp >95F
Canopy Closed & Latched
Mag checks 1700 RPM
Prop Cycle, then forward
EFIS PFD mode
Flaps As needed
Takeoff Briefing Complete
Flight Controls Free and Correct
Mixture Full rich, as needed
Fuel Pump On

Climb check

Flaps Up
Fuel Pump Off

Before Landing

Landing Briefing Complete
Fuel Pump On
Mixture Full rich, as needed
Prop Forward

Before Shutdown

Flaps Down
Mixture ICO
Purge Open, then closed
All switches Off
CO detector Off

HB-YMM
2021-01-30

